



Standard Design Kits

PPI
Passive Plus Inc.
RF & Microwave Components

DKD0201N01

0201N Series 0.1 — 2.0pF
Size: 0.020" x 0.010"
TC = NP0 WVDC = 50V

Hi-Q Low ESR Capacitor Design Kit



www.passiveplus.com

PPI
Passive Plus Inc.
RF & Microwave Components

DKD0402N01

0402N Series 0.1 — 2.0pF
Size: 0.040" x 0.020"
TC = NP0 WVDC = 200V

Hi-Q Low ESR Capacitor Design Kit



www.passiveplus.com

PPI
Passive Plus Inc.
RF & Microwave Components

DKD0603N01

0603N Series 0.1 — 2.0pF
Size: 0.060" x 0.030"
TC = NP0 WVDC = 250V

Hi-Q Low ESR Capacitor Design Kit



www.passiveplus.com

PPI
Passive Plus Inc.
RF & Microwave Components

DKD0708N01

0708N Series 1.0 — 10pF
Size: 0.070" x 0.080"
TC = NP0 WVDC = 500V

Hi-Q Low ESR Capacitor Design Kit



www.passiveplus.com

PPI
Passive Plus Inc.
RF & Microwave Components

DKD0805N01

0805N Series 0.1 — 2.0pF
Size: 0.080" x 0.050"
TC = NP0 WVDC = 250V

Hi-Q Low ESR Capacitor Design Kit



www.passiveplus.com

PPI
Passive Plus Inc.
RF & Microwave Components

DKD1111N01

1111N Series 1.0 — 10pF
Size: 0.110" x 0.110"
TC = NP0 WVDC = 500V

Hi-Q Low ESR Capacitor Design Kit



www.passiveplus.com

PPI
Passive Plus Inc.
RF & Microwave Components

DKD0505C01

0505C Series 0.1 — 2.0pF
Size: 0.055" x 0.055"
TC = NP0 WVDC = 150V

Hi-Q Low ESR Capacitor Design Kit



www.passiveplus.com

PPI
Passive Plus Inc.
RF & Microwave Components

DKD1111C01

1111C Series 1.0 — 10pF
Size: 0.110" x 0.110"
TC = NP0 WVDC = 500V

Hi-Q Low ESR Capacitor Design Kit



www.passiveplus.com

PPI
Passive Plus Inc.
RF & Microwave Components

DKD0505P01

0505P Series 0.1 — 2.0pF
Size: 0.055" x 0.055"
TC = P90 WVDC = 150V

Hi-Q Low ESR Capacitor Design Kit



www.passiveplus.com



0505 & 1111 case size kits
are available in
Magnetic & Non-Magnetic
Terminations

PPI
Passive Plus Inc.
RF & Microwave Components

DKD1111P01

1111P Series 1.0 — 10pF
Size: 0.110" x 0.110"
TC = P90 WVDC = 500V

Hi-Q Low ESR Capacitor Design Kit



www.passiveplus.com

High Q Capacitor Design Kits

According to the customer's demand, PPI can provide many kinds of tool kits for engineers to design and debug the circuit. All of our products satisfy the requirement of RoHS instruction.

PPI also offers kits for Non-Magnetic MRI applications. Engineering design kits are also available in multiple sizes as well. All kits are RoHS Compliant.

Standard Values updated in 2022.



Kit Number		Value Range	Values
Magnetic	Non-Magnetic		
DKD0505C01	DKD0505C05	0.1 - 2.0pF	0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7, 0.8, 0.9, 1.0, 1.2, 1.5, 1.6, 1.8, 2.0pF
DKD0505P01	DKD0505P05		
DKD0505C02	DKD0505C06	1 - 10pF	1.0, 1.2, 1.5, 1.8, 2.0, 2.2, 2.4, 2.7, 3.0, 3.3, 3.9, 4.7, 5.6, 6.8, 8.2, 10pF
DKD0505P02	DKD0505P06		
DKD0505C03	DKD0505C07	10 - 100pF	10, 12, 15, 18, 20, 22, 24, 27, 30, 33, 39, 47, 56, 68, 82, 100pF
DKD0505P03	DKD0505P07		
DKD0505C04	DKD0505C08	100 - 1000pF	100, 120, 150, 180, 200, 220, 240, 270, 300, 330, 390, 470, 560, 680, 820, 1000pF
DKD1111C01	DKD1111C05	1.0 - 10pF	1.0, 1.2, 1.5, 1.8, 2.0, 2.2, 2.4, 2.7, 3.0, 3.3, 3.9, 4.7, 5.6, 6.8, 8.2, 10pF
DKD1111P01	DKD1111P05		
DKD1111C02	DKD1111C06	10 - 100pF	10, 12, 15, 18, 20, 22, 24, 27, 30, 33, 39, 47, 56, 68, 82, 100pF
DKD1111P02	DKD1111P06		
DKD1111C03	DKD1111C07	100 - 1000pF	100, 120, 150, 180, 200, 220, 240, 270, 300, 330, 390, 470, 560, 680, 820, 1000pF
DKD1111P03	DKD1111P07		
DKD1111C04	DKD1111C08	1000 - 10000pF	1000, 1100, 1200, 1500, 1800, 2000, 2200, 2700, 3000, 3300, 3900, 4700, 5100, 5600, 10000pF
DKD1111P04	DKD1111P08		



Standard Design Kits

⚡ EIA Low ESR Design Kits

Kit Number	Value Range	Values
DKD0201N01	0.1 - 2.0pF	0.1, 0.2, 0.3, 0.5, 0.7, 0.8, 0.9, 1.0, 1.3, 1.5, 1.7, 1.9, 2.0pF
DKD0201N02	1.0 - 10pF	1.0, 1.3, 1.5, 1.7, 1.9, 2.0, 2.2, 2.7, 3.0, 3.9, 4.7, 5.6, 6.8, 7.5, 8.2, 10pF
DKD0201N03	10 - 47pF	10, 13, 15, 18, 20, 22, 27, 30, 39, 47pF
DKD0402N01	0.1 - 2.0pF	0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7, 0.8, 0.9, 1.0, 1.2, 1.5, 1.6, 1.8, 2.0pF
DKD0402N02	1.0 - 10pF	1.0, 1.2, 1.5, 1.8, 2.0, 2.2, 2.4, 2.7, 3.0, 3.3, 3.9, 4.7, 5.6, 6.8, 8.2, 10pF
DKD0402N03	10 - 33pF	10, 12, 13, 15, 16, 18, 20, 22, 24, 27, 30, 33pF
DKD0603N01	0.1 - 2.0pF	0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7, 0.8, 0.9, 1.0, 1.1, 1.2, 1.5, 1.6, 1.8, 2.0pF
DKD0603N02	1.0 - 10pF	1.0, 1.2, 1.5, 1.8, 2.0, 2.2, 2.4, 2.7, 3.0, 3.3, 3.9, 4.7, 5.6, 6.8, 8.2, 10pF
DKD0603N03	10 - 100pF	10, 12, 15, 18, 20, 22, 24, 27, 30, 33, 39, 47, 56, 68, 100pF
DKD0708N01	1.0 - 10pF	1.0, 1.2, 1.5, 1.8, 2.0, 2.2, 2.4, 2.7, 3.0, 3.3, 3.9, 4.7, 5.6, 6.8, 8.2, 10pF
DKD0708N02	10 - 100pF	10, 12, 15, 18, 20, 22, 24, 27, 30, 33, 39, 47, 56, 68, 82, 100pF
DKD0805N01	0.1 - 2.0pF	0.1, 0.2, 0.3, 0.4, 0.5, 0.6, 0.7, 0.8, 0.9, 1.0, 1.2, 1.5, 1.6, 1.8, 2.0pF
DKD0805N02	1.0 - 10pF	1.0, 1.2, 1.5, 1.8, 2.0, 2.2, 2.4, 2.7, 3.0, 3.3, 3.9, 4.7, 5.6, 6.8, 8.2, 10pF
DKD0805N03	10 - 100pF	10, 12, 15, 18, 20, 22, 24, 27, 30, 33, 39, 47, 56, 68, 82, 100pF
DKD0805N04	10 - 220pF	10, 15, 18, 20, 24, 27, 30, 39, 47, 56, 68, 82, 100, 120, 150, 180, 220pF
DKD1111N01	1.0 - 10pF	1.0, 1.2, 1.5, 1.8, 2.0, 2.2, 2.4, 2.7, 3.0, 3.3, 3.9, 4.7, 5.6, 6.8, 8.2, 10pF
DKD1111N02	10 - 100pF	10, 12, 15, 18, 20, 22, 24, 27, 30, 33, 39, 47, 56, 68, 82, 100pF
DKD1111N03	100 - 1000pF	100, 120, 150, 180, 200, 220, 240, 270, 300, 330, 390, 470, 560, 680, 820, 1000pF



Custom Kits

According to the customer's demand, PPI can provide many kinds of tool kits for engineers to design and debug the circuit. All our products satisfy the requirement of RoHS instruction.

Passive Plus will develop a custom kit using the engineer's specific requirements for the engineer's projects (case size, temperature coefficient, value range, tolerances, voltages, and quantities per value). Once these requirements are determined, PPI will then provide customer with a price. Please contact PPI directly to start this process.

All kits are RoHS Compliant.





Custom Kits

